

MetaSole

On-roof system

Installation Guide



1 Push end clamp on the bottom clamp base



2 Installation of the lower clamp base

self-drilling screw EJOT for trapazoidal sheet thickness from 0,4 mm - 1 mm

self-drilling screw SFS for trapazoidal sheet thickness from 0,75 mm - 1 mm



3 Mount the clamp bases in the middle

self-drilling screw EJOT for trapazoidal sheet thickness from 0,4 mm - 1 mm

self-drilling screw SFS for trapazoidal sheet thickness from 0,75 mm - 1 mm



4 Mount the top clamp bases



5 Mount the middle clamp



6 Mount PV modules



7 *MetaSole*



8 *MetaSole*